

XIAOMI MIJIA Vacuum Cleaner 2

XIAOMI MIJIA Vacuum Cleaner 2 Instruction Manual

Model: MIJIA Vacuum Cleaner 2

INTRODUCTION

Thank you for choosing the XIAOMI MIJIA Vacuum Cleaner 2. This powerful and versatile corded vacuum cleaner is designed for efficient home sweeping and cleaning, featuring strong cyclone suction and a multi-layer filtration system. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance.

IMPORTANT SAFETY INSTRUCTIONS


Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the voltage specified on the appliance.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids. This appliance is primarily designed for dry cleaning.
- Do not pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not pick up burning or smoking materials such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not use without the dust cup and filters properly in place.
- Unplug from the electrical outlet when not in use and before cleaning or servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- Main unit × 1
- Extension rod × 1
- Floor Main brush × 1
- User manual × 1
- Crevice nozzle × 1
- Brush nozzle × 1



PRODUCT OVERVIEW AND FEATURES

The XIAOMI MIJIA Vacuum Cleaner 2 is engineered for powerful and convenient cleaning. Key features include:

- **Powerful Suction:** Equipped with a 600W high-performance motor, delivering up to 16kPa strong cyclone suction for effective dust removal.
- **Advanced Filtration:** Features a 5-layer depth filtration system, achieving a filtration efficiency of up to 99.7%, preventing secondary pollution.
- **Transparent Dust Cup:** A 0.5L transparent dust cup allows you to monitor dust levels and is easily detachable for emptying.
- **Wide Cleaning Path:** A 240mm large suction port covers more cleaning areas and effectively addresses blind spots.
- **Lightweight Design:** The main unit weighs only 1.6Kg, making it labor-saving and easy to maneuver for extended cleaning sessions.
- **Versatile Attachments:** Includes a floor brush, a long flat nozzle, and a brush nozzle for various cleaning tasks.
- **Washable Components:** Dust cup, stainless steel filter, filter element, and filter cotton are all washable for hygienic and eco-friendly maintenance.
- **Thoughtful Design:** Features a one-key switch for easy operation, durable ABS material construction, and tight linear cooling vents for efficient heat dissipation.



Figure 2: Highlighting the 16kPa powerful suction and the 5-layer filtration system.



Figure 3: Details of the vacuum cleaner's thoughtful design elements.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all components from the packaging. Refer to the "Package Contents" section to ensure all parts are present.
2. **Assemble the Main Unit:**
 - Attach the extension rod to the main unit until it clicks securely into place.
 - Select the desired cleaning attachment (floor main brush, crevice nozzle, or brush nozzle) and attach it to the end of the extension rod or directly to the main unit for handheld use.
3. **Power Connection:**

- This is a corded vacuum cleaner. Ensure the power cord is fully extended before plugging it into an electrical outlet.
 - **Plug Adapter:** The product is supplied with a Chinese standard plug. A correct plug adapter or conversion plug for your country will be included in the package. Please use the appropriate adapter for your region.
4. **Wall-Mounted Storage (Optional):** The vacuum cleaner comes with a wall-mounted storage rack. Install this rack in a convenient location according to the separate instructions provided with the rack (if any) or by securely mounting it to a wall using appropriate hardware. This rack also provides storage for the power cable.





We Will Send You The Correct Plug Adapter or Conversion Plug For Your Country.	
	EU Plug Adapter (2 Pin Round Pin) Spain, France, Germany, Netherlands, Poland, etc Most Europe Countries, Most African Countries, Most Middle East Countries, SouthKorea, Chile, Paraguay, etc.
	US Plug Adapter (2 Pin Flat Pin) USA, Canada, Japan, Brazil, Philippines, Thailand, Most North and South American Countries,
	Australia/New Zealand (2 Pin Plug Adapter) Australia, New Zealand, Argentina
	UK Plug Adapter (3 Pin Flat Pin) England, Ireland, Scotland, Hongkong, Pakistan, Singapore, Malaysia, Vietnam, etc.

Figure 4: Guide to plug adapters provided for different regions.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Plug the vacuum cleaner into a suitable electrical outlet. Press the one-key switch located on the main unit to turn the vacuum cleaner ON. Press it again to turn OFF.
2. **Using the Floor Main Brush:**
 - Attach the floor main brush to the extension rod for cleaning floors and carpets.
 - The 4cm low-profile design of the floor brush allows for easy cleaning under furniture without needing to move heavy items.
3. **Using Crevice and Brush Nozzles:**
 - Attach the crevice nozzle directly to the main unit or extension rod to reach narrow gaps, corners, and edges.
 - Attach the brush nozzle for cleaning delicate surfaces, upholstery, curtains, and high places like ceiling corners.
4. **Handheld Operation:** For quick clean-ups or cleaning elevated surfaces, detach the extension rod and attach the desired nozzle directly to the main unit. The lightweight design (1.6Kg main unit) makes handheld use comfortable.



Figure 5: Demonstrating the versatility of the vacuum cleaner for different cleaning tasks.

1.6kg^[5]



Figure 6: The low-profile floor brush easily cleans under furniture.

MAINTENANCE AND CLEANING

Regular maintenance ensures the optimal performance and extends the lifespan of your vacuum cleaner.

1. Emptying the Dust Cup:

- The 0.5L transparent dust cup should be emptied regularly, especially when the dust level reaches the MAX line.
- To empty, press the one-key release button on the dust cup to detach it from the main unit.
- Hold the dust cup over a trash bin and open the bottom flap to release the collected debris.
- Reattach the dust cup securely to the main unit after emptying.

2. Cleaning Filter Components:

- The dust cup, stainless steel filter, filter element, and filter cotton are all washable.
- Detach the dust cup and disassemble the filter components (stainless steel filter, filter element, filter cotton).
- Rinse all washable components under running water until clean. Do not use harsh detergents.
- Ensure all components are completely dry before reassembling them into the dust cup and reattaching to the main unit. Air drying is recommended; avoid direct sunlight or heat.

3. Cleaning the Main Unit and Attachments:

- Wipe the exterior of the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- Periodically check the floor brush for tangled hair or debris and remove them to maintain effective cleaning.



Figure 7: Detaching the 0.5L transparent dust cup for emptying.



Figure 8: Washable filter components being cleaned.

TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in, power outlet malfunction, power cord damage, switch malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the power cord for any visible damage. If damaged, contact support.
Weak suction.	Full dust cup, clogged filters, blocked nozzle/hose, foreign object in air duct.	Empty the dust cup. Clean all filter components thoroughly and ensure they are dry before reassembly. Check nozzles, extension rod, and air duct for blockages and remove them.
Unusual noise during operation.	Foreign object in brush roll or air duct, motor issue.	Turn off and unplug the vacuum. Inspect the brush roll and air duct for any foreign objects and remove them. If the noise persists, contact customer support.
Plug does not fit the outlet.	Incorrect plug type for your region.	Ensure you are using the correct plug adapter provided with the product for your country. If the adapter is missing or incorrect, contact customer support.
Missing parts (e.g., storage bracket).	Packaging error.	Immediately contact customer support with your purchase details to arrange for the missing part to be sent.
Damage to parts (e.g., wrinkle tube on head).	Wear and tear, accidental damage.	Contact customer support to inquire about replacement parts. Do not attempt to repair damaged components yourself if it compromises safety or functionality.

SPECIFICATIONS

Technical specifications for the XIAOMI MIJIA Vacuum Cleaner 2:

Feature	Specification
Brand Name	XIAOMI
Model	MIJIA Vacuum Cleaner 2
Power (W)	600W
Suction Power	16kPa
Voltage	220V
Plug Standard	Chinese (adapter included for regional compatibility)
Function	Dry Cleaning
Dust Storage Type	Dust Box (Bagless)

Feature	Specification
Dust Box Capacity (L)	0.5 L
Filter Type	HEPA (5-layer depth filtration)
Installation	Hand Held
Weight	Main unit <3 kg (approx. 1.6Kg)
Size (mm)	240 * 250 * 1173mm
Cord Length (m)	About 5 meters
Number of Nozzles	1-3 (Floor brush, Crevice nozzle, Brush nozzle)
Turbo Brush	Yes
LCD	No
Remote Control	No
Certification	CE
Origin	Mainland China





USER TIPS

- **Plug Compatibility:** Always ensure you are using the correct plug adapter for your region to prevent electrical issues. If you received an incorrect plug or adapter, contact customer support immediately.
- **Regular Filter Cleaning:** To maintain strong suction and prevent motor strain, clean the washable filter components frequently. Allow them to air dry completely before reinstallation.
- **Check for Blockages:** If suction power decreases, first check the dust cup, filters, and all nozzles/hoses for any blockages before assuming a malfunction.
- **Part Replacement:** In case of damage to specific parts like the vacuum head or flexible tubes, contact customer support to inquire about purchasing replacement parts rather than attempting makeshift repairs.

WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please contact the seller or the official XIAOMI customer service in your region. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - MIJIA Vacuum Cleaner 2

 <p>Руководство по эксплуатации пылесоса Xiaomi Mijia G1 Sweeping Vacuum Cleaner</p>	<p>Xiaomi Mijia G1 Sweeping Vacuum Cleaner User Manual Comprehensive user manual for the Xiaomi Mijia G1 Sweeping Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, and safety precautions.</p>
 <p>Руководство по эксплуатации пылесоса Xiaomi Mijia G1 Sweeping Robot G1</p>	<p>Xiaomi Mijia Sweeping Robot G1 User Manual and Specifications This document provides a comprehensive user manual for the Xiaomi Mijia Sweeping Robot G1 (Model MJSTG1). It includes detailed instructions on installation, operation, maintenance, troubleshooting common errors, and technical specifications for the robot vacuum, charging dock, and power adapter. Ensure safe and efficient use of your Xiaomi robot vacuum by following the guidelines provided.</p>
 <p>Руководство по эксплуатации пылесоса Xiaomi Mijia 1S Sweeping Robot G1</p>	<p>Xiaomi Mijia Sweeping Robot 1S Instruction Manual - Setup, Operation, and Maintenance Comprehensive user manual for the Xiaomi Mijia Sweeping Robot 1S, covering setup, cleaning modes, maintenance, troubleshooting, and safety precautions.</p>
 <p>Руководство по эксплуатации пылесоса Xiaomi Mijia Vacuum Cleaner Pro MJSTS1</p>	<p>Руководство пользователя и инструкции для робота-пылесоса Xiaomi Mijia Vacuum Cleaner Pro MJSTS1 Полное руководство пользователя для робота-пылесоса Xiaomi Mijia Vacuum Cleaner Pro (Модель MJSTS1), охватывающее безопасность, настройку, эксплуатацию, техническое обслуживание, устранение неполадок и технические характеристики.</p>



[Xiaomi Dust Mite Vacuum Cleaner Pro User Manual](#)

This user manual provides comprehensive instructions for operating and maintaining the Xiaomi Dust Mite Vacuum Cleaner Pro. It covers safety precautions, product overview, usage guidelines, cleaning and maintenance procedures, troubleshooting common issues, technical specifications, and compliance information.



[Xiaomi Dust Mite Vacuum Cleaner Pro Filter User Manual](#)

Comprehensive user manual for the Xiaomi Dust Mite Vacuum Cleaner Pro Filter. Learn how to install, clean, and maintain your filter for optimal performance. Includes specifications and important precautions.